

CONTROLLER OPERATION

REVERSER (FWD-NEU-REV)

- 1] REVERSER HANDLE IN
- 2] THROTTLE-STOP OR IDLE
- 3] DYN BRK OFF

THROTTLE (STOP THRU 8)

- 1] REVERSER HANDLE IN
- 2] REV ANY POSITION
- 3] DYN BRK-OFF

DYN BRK (OFF THRU 8)

- 1] REVERSER HANDLE IN
- 2] REVERSER FWD OR REV
- 3] THROTTLE-STOP OR IDLE

TRAILING UNIT SET UP

- 1] THROTTLE-IDLE
- 2] DYN BRK-OFF
- 3] REV HANDLE REM'D